

LISTE DES CODES USINE

MARQUE	GENRE	MODELE	CODE USINE
ENGEL	TNT	RT0302U	1307
	TNT	RT 7130T2	0000
HITACHI	TNTSAT	HDB981E	9102
SERVIMAT	TNT	TNT58 TNT59USB TNT62	3101
	TNT	TNT63	3327
	TNT	TNT70HD2	0000
	FRANSAT	TSF8000HD TSF8500H DU	touche bleu / touche bleu / 4000
	FRANSAT	TSF8600H DU	4000
	FRANSAT	TSV5000	2606
	TNTSAT	TSV6000 TSV7500H DU TSV6500HD	touche bleu / touche bleu / 4000
	TNTSAT	TSV7600H DU VEGA	4000
	FRANSAT	SIRIUS	4000
SAGEM	TNTSAT	DS81HD	0044
STRONG	TNTSAT	SRT7400	1004
	TNT	SRT80 SRT8105ECO	2004
	TNT	SRT8112 SRT8115	1234
	TNT	SRT8102+ SRT8210	0000
	FTA	SRT7002HD SRT7004 SRT7300CI	0000
	TNTSAT	SRT8110	8888
THOMSON	FTA	THS222	0000
	TNTSAT	THS800 THS801 (ou THT801) THS804	1004 ou 2004
	FRANSAT	THS802 THS803 THS805	
	TNT	THT 503 / THT 504+	1234
	TNT	THT91 THT101 THT501 TTR100 TTR110	0000
TRIAx	FTA	S-HD11 S-HD12	3327
	TERRESTRE	TR63 TR65	3327
	FRANSAT	THR7610 / 7620	4000
	TNTSAT	THR9910 THR9930	4000
VISIOSAT / CAHORS	TNTSAT	TEOX	6787
	FTA	TVS6500 HD	0000
	TNT	TVT100 SCART TVT 250 HDR TVT 250 USB+	0000
	TNT	TVT100 SCART TVT 280	000000
	FRANSAT	VEOX	6787
WISI	FRANSAT	OR03S	2606